



ASSEMBLY INSTRUCTIONS:

1. SLIDE THE HOOKS ON THE SIDE RAILS (B) INTO THE SLOTS LOCATED ON THE HEADBOARD (A) AND FOOTBOARD (C) .PRESS DOWN UNTIL THEY CLICK TO SECURE"
2. PUT IN THE BASE BOARDS VERTICAL (G).
3. CONNECT THE METAL MATTRESS SUPPORT(I)TO THE FRAME (H) USING BOLTS AND NUTS.
4. EXTEND THE MECHANISM UPWARDS AND SECURE THE METAL SLAT FRAME ONTO IT BY SCREW .ENSURE THE METAL SLAT FRAME IS CORRECTLY ALIGNED TO FIT INSIDE THE BED,BEFORE TIGHTENING THE SCREWS.
5. TIE HANDLE (S)TO THE SLAT
6. ONLY LIFT THE BED FRAME WHEN A MATTRESS IS IN POSITION.